



## Life Saver Of Houston

9202 Solvista Pass Lane, Houston, Texas 77070

(832) 367-2377

[www.BestPoolFenceHouston.com](http://www.BestPoolFenceHouston.com)



## Instructions – Maintaining A Safe Pool Fence

### Cleaning Instructions (Should be performed twice a year)

- While fence is up and fully attached, simply take a bucket of water with mild soap and using a cloth clean mesh and poles. Then rinse clean with a hose and spray nozzle attachment.
- Release the tension on the fence by unlatching the safety locks on each section. Do this until all sections are unlocked.
- Remove one section at a time. Using a hose flush out the deck insert until water runs clear. With a damp cloth clean the bottom of each pole.
- Reinsert the section of clean fence back into the deck sleeves.
- Follow these steps for each section until entire fence is clean.
- Lock all safety latches until fence is secure.

### Self-Closing Gate Adjustments (Should be done every time fence is removed and checked periodically)

Your new Life Saver Self-Closing Gate comes equipped with built in adjustments as follows:

- Tru-Close Hinges - To adjust, simply remove with a phillips head screw driver the caps on the top of each hinge. Using a broad tip flat head screwdriver, insert into slot depress and turn towards plus sign to close faster or minus sign to close slower. Make sure that after you depress and turn, the adjustment pops back up and locks into a different



position.

- **Striker Body** (located on the gate frame) - To adjust, locate silver screw in center side of striker body. Using a Philips head screw driver simply turn clock-wise or counter clock-wise to slide striker body horizontally either left or right. Make sure the catch of the striker body centers up with the center of the latch body.
- **Latch Body** (located on the locking post) - To adjust, simply remove locking screw (using a Philips head screw driver) located at the bottom of the latch body. Now you can slide the latch body either up or down for vertical adjustment. Once adjusted replace locking screw.



## **Trouble Shooting Guide**

*I can't remove the pole from the deck insert?*

- Are you trying to remove the pole properly? The fence works on tension. There is a linear force being exerted on the fence at all times. To remove pole properly you must place one hand on the top of the pole and one hand mid-way down the pole. Next, using your body weight and not your arm strength lean on the pole until it is vertical in the deck sleeve. You will know you are leaning on the pole correctly when the space between the deck sleeve and the bottom of the pole is equal all the way around. While leaning on the pole correctly pull straight up. This should be one complete motion. If this does not work do the same motion while twisting the pole. If this continues to happen, you need to follow cleaning instructions or unlock the latch at both ends of section then try to remove pole properly.

*I can't put the pole back into the deck insert?*

- First, follow cleaning instructions for pole and deck sleeve. If the pole still will not go in make sure that you are not trying to enter the hole straight on. Always have a slight tilt on the pole in order to align pole to hole.

*The fence is loose.*

- Make sure all latches are securely locked together and all poles are inserted fully into the deck sleeves.
- You should never hang anything from the fence. This includes wet towels.

*The bottom border of my fence is losing the poly-vinyl coating.*

- Check to make sure your landscaper is not hitting the fence with a weed wacker.

*I am noticing holes in my fence.*

- Check to make sure your landscaper is not leaning on the fence and burning holes in it with the hot muffler on the blower pack.

*I can't open the gate section of the fence.*

- Make sure that the eyelets are facing directly outwards. Next, grab the top of one pole locking the pole between your thumb and your palm to prevent the turning of eyelets. Now squeeze the poles together so that the latch is floating between the two eyelets. You can now release the latch and pull one side of latch free from the one eyelet. Proceed to remove pole from ground correctly to open gate section.



*I can't close the gate section.*

- Turn poles so that the eyelets are facing directly outwards. Next, grab the top of one pole locking the pole between your thumb and your palm to prevent the turning of eyelets. Lean that pole (using your body weight) towards the opposing pole until you can grab the opposing pole with your hand. Squeeze poles together until latch can reach opposing eyelet. Pull latch back and loop through eyelet. Let go of release on latch to lock sections together.

If You Have Any Other Questions, Don't Hesitate To Call:

**Life Saver Of Houston**

(832) 367-2377